


INPUT: 220-240~50/60Hz CLASS I	IP20	△
LAMP-HOUSE: MR16-40W (MAX.)	0.5m	CE
MATERIAL.: ALUMINTUM		

⚠ CAUTION:WHILE THE LAMP IS WORKING,THE SURFACE OF IT IS VERY HOT,PLEASE DO NOT TOUCH!



Item NO. :CLT 222



INSTALL ATION INSTRUCTION

- 1.Before installing,make sure the power supply is switched off.
- 2.Follow the steps as the figure for installation or replacement of bulb

Step:

- A.after holing,pull out the wires.
- B.fix the bracket to the wall with screws.
- C.connect the wires to the terminal block.
- D.fix the lamp body to the base with screws.
- E.insert the bulb with gasket to the lamp body.
- F.secure the bulb with lamp shade by twist in clockwise.

- 3.After finishing every step,tighten the screws,have the fixture fixed,and then connect the power supply.

CLEANING INSTRUCTION

- 1.Before cleaning,ensure that the power supply is switched off.
- 2.Use only a soft cloth to clean the lamp,dampened with mild cleanser if needed for resistant dirt.
- 3.Warning:do not use alcohol or other solvents.

CAUTION:

While the lamp is working,the surface of it is hot!
Please do not touch the fixture within an hour after the power supply has been switched off.

