





ATTENTION!
 Installation and changing arm direction should be carried out by electrician.
 Power should be cut off before cleanliness or bulds changing



Instruction
Ceiling

