Assembling

LIGHTSOLE LOFT



User's guide
Installation and maintenance

General information

- The fixture is used for [illegible]
- The fixture should be [illegible] 220V and frequency of 50Hz.
- The fixture can be [illegible] electrical circuit.
- IP20.

Contents

- Lamp
- User's guide
- Fasteners

Safety requirements

- Before installation [illegible]
- Installation procedures should be [illegible] If you are not experienced in installing electrical [illegible]
- All the work should be carried out with the electrical power supply is switched off.
- Make sure that your electrical power [illegible] before installing product.
- It is strictly forbidden to use lamps if fixtures in power and shades from [illegible] this manual.
- Prevent shock from and damage.
- For cleaning use dry soft cloth. Don't use [illegible] water.
- Wiring should be carried only by qualified electrical staff, who is authorized for this kind of work.
- If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent in a similar qualified person in order to avoid a hazard.

Installation and maintenance

- Unpack the fixture and make sure it is intact.
- Install the fixture following attached scheme.
- Before changing lamp make sure the fixture is [illegible] at least [illegible] min.
- Do not use more powerful bulbs than it is recommended in this manual.
- Don't touch halogen bulb [illegible] dry cloth.
- Keep the fixture [illegible] if it doesn't need light at the moment.

Warranty

- The [illegible] warranty [illegible] from the date of [illegible] of the warranty coupon.
- If [illegible] defect [illegible] the warranty [illegible] the warranty.
- Manufacturer [illegible] without selling stamp and [illegible] in the warranty coupon.
- Guaranteed life period in keeping to safety requirements is [illegible] years.
- Claims and request should be sent to E-mail: sales@LightYourLoft.com

Гарантийный талон
Подробные характеристики светильника

Общие сведения

- [illegible]
- [illegible]
- [illegible]

Комплектация

- [illegible]
- [illegible]
- [illegible]

Технические требования

- [illegible]
- [illegible]
- [illegible]
- [illegible]
- [illegible]
- [illegible]
- [illegible]
- [illegible]

Требования к установке и эксплуатации

- [illegible]
- [illegible]
- [illegible]
- [illegible]
- [illegible]
- [illegible]

Гарантийные обязательства

- Сервис поставщик гарантирует работу светильника в течение 12 месяцев со дня продажи при соблюдении [illegible]
- В случае обнаружения [illegible]
- [illegible]
- Срок службы [illegible]
- Претензии и пожелания потребителей принимаются по адресу E-mail: info@lightsole.ru

Гарантийный талон

Дата изготовления: [illegible] 20[illegible] г. Подпись ответственного лица